



RabbitCore RCM2300

C-Programmable Module

User's Manual

019-0099 • 030731-C

RabbitCore RCM2300 User's Manual

Part Number 019-0099 • 030731-C • Printed in U.S.A.

© 2001–2003 Z-World, Inc. • All rights reserved.

Z-World reserves the right to make changes and improvements to its products without providing notice.

Trademarks

Rabbit and Rabbit 2000 are registered trademarks of Rabbit Semiconductor.

RabbitCore is a trademark of Rabbit Semiconductor.

Dynamic C is a registered trademark of Z-World Inc.

Z-World, Inc.

2900 Spafford Street
Davis, California 95616-6800
USA

Telephone: (530) 757-3737
Fax: (530) 757-3792

www.zworld.com

Rabbit Semiconductor

2932 Spafford Street
Davis, California 95616-6800
USA

Telephone: (530) 757-8400
Fax: (530) 757-8402

www.rabbitsemiconductor.com

TABLE OF CONTENTS

Chapter 1. Introduction	1
1.1 RabbitCore RCM2300 Features.....	1
1.2 Advantages of the RabbitCore RCM2300	2
1.3 Development and Evaluation Tools.....	2
1.4 How to Use This Manual	3
1.4.1 Additional Product Information	3
1.4.2 Additional Reference Information	3
1.4.3 Using Online Documentation	3
Chapter 2. Hardware Reference	5
2.1 RCM2300 Digital Inputs and Outputs	5
2.1.1 Dedicated Inputs	9
2.1.2 Dedicated Outputs	9
2.1.3 Memory I/O Interface	9
2.1.4 Other Inputs and Outputs	9
2.2 Serial Communication	10
2.2.1 Serial Ports	10
2.2.2 Programming Port	10
2.3 Other Hardware.....	12
2.3.1 Clock Doubler	12
2.3.2 Spectrum Spreader	12
2.4 Memory.....	13
2.4.1 SRAM	13
2.4.2 Flash EPROM	13
2.4.3 Dynamic C BIOS Source Files	13
Chapter 3. Software Reference	15
3.1 More About Dynamic C	15
3.2 Programming Cable	16
3.2.1 Changing from Program Mode to Run Mode	16
3.2.2 Changing from Run Mode to Program Mode	16
3.3 Dynamic C Libraries.....	17
3.3.1 I/O	17
3.3.2 Serial Communication Drivers	17
3.4 Sample Programs	19
3.5 Upgrading Dynamic C	20
3.5.1 Upgrades	20
Appendix A. RabbitCore RCM2300 Specifications	21
A.1 Electrical and Mechanical Characteristics	22
A.1.1 Headers	25
A.1.2 Physical Mounting	25
A.2 Bus Loading	26
A.3 Rabbit 2000 DC Characteristics.....	28
A.4 I/O Buffer Sourcing and Sinking Limit	29
A.5 Conformal Coating.....	30
A.6 Jumper Configurations.....	31

Appendix B. Prototyping Board	33
B.1 Mechanical Dimensions and Layout	34
B.2 Power Supply.....	35
B.3 Using the Prototyping Board	35
B.3.1 Adding Other Components	38
B.3.2 Attach Modules to Prototyping Board	39
Appendix C. Power Supply	41
C.1 Power Supplies	41
C.2 Battery Backup	41
C.2.1 Battery Backup Circuits	44
C.2.2 Reset Generator	44
C.3 Chip Select Circuit.....	45
Appendix D. Programming Cable	47
Appendix E. Sample Circuits	51
E.1 RS-232/RS-485 Serial Communication.....	52
E.2 Keypad and LCD Connections	53
E.3 External Memory	54
E.4 D/A Converter.....	55
Notice to Users	57
Index	59
Schematics	61

1. INTRODUCTION

The RabbitCore RCM2300 is a very small advanced core module that incorporates the powerful Rabbit 2000™ microprocessor, flash memory, static RAM, and digital I/O ports, all on a PCB that is just 1.15" × 1.60" (29.2 mm × 40.6 mm).

The RCM2300 has a Rabbit 2000 microprocessor operating at 22.1 MHz, static RAM, flash memory, two clocks (main oscillator and timekeeping), and the circuitry necessary for reset and management of battery backup of the Rabbit 2000's internal real-time clock and the static RAM. Two 26-pin headers bring out the Rabbit 2000 I/O bus lines, address lines, data lines, parallel ports, and serial ports.

The RCM2300 receives its +5 V power from the user board on which it is mounted. The RabbitCore RCM2300 can interface with all kinds of CMOS-compatible digital devices through the user board.

1.1 RabbitCore RCM2300 Features

- Small size: 1.15" × 1.60" × 0.48"
(29 mm × 41 mm × 12 mm)
- Microprocessor: Rabbit 2000 running at 22.1 MHz
- 29 parallel I/O lines: 17 configurable for input or output, 8 fixed inputs, 4 fixed outputs
- 11 additional I/O are available via less convenient 0.03" diameter through-hole connection points
- 8 data lines (D0–D7)
- 4 address lines (A0–A3)
- Memory I/O read, write
- External reset input
- Five 8-bit timers (cascadable in pairs) and one 10-bit timer with two match registers
- 256K flash memory, 128K SRAM
- Real-time clock
- Watchdog supervisor

- Provision for customer-supplied backup battery either onboard or via header connections
- Four CMOS-compatible serial ports. All the serial ports can be configured asynchronously, and two serial ports can be configured synchronously if so desired. The maximum asynchronous baud rate is 691,200 bps (Dynamic C drivers are capable of handling up to the sustained rate of 345,600 bps), and the maximum synchronous baud rate is 5.5296 Mbps (user-written drivers can sustain a rate of 2.7648 Mbps). One synchronous port clock line is available only on the programming header.
- The programming port is also routed to the 26-pin headers, which allows the user board the ability to reprogram the RCM2300.

Appendix A, “RabbitCore RCM2300 Specifications,” provides detailed specifications for the RCM2300.

1.2 Advantages of the RabbitCore RCM2300

- Fast time to market using a fully engineered, “ready to run” microprocessor core.
- Competitive pricing when compared with the alternative of purchasing and assembling individual components.
- Easy C-language program development and debugging, including rapid production loading of programs.
- Generous memory size allows large programs with tens of thousands of lines of code, and substantial data storage.
- Very small size.

1.3 Development and Evaluation Tools

A complete Development Kit, which includes a Prototyping Board and Dynamic C development software, is available for the RCM2300. The Development Kit puts together the essentials you need to design an embedded microprocessor-based system rapidly and efficiently.

See the *RabbitCore RCM2300 Getting Started Manual* for complete information on the Development Kit.

1.4 How to Use This Manual

This user's manual is intended to give users detailed information on the RCM2300 module. It does not contain detailed information on the Dynamic C development environment. Most users will want more detailed information on some or all of these topics in order to put the RCM2300 module to effective use.

1.4.1 Additional Product Information

Introductory information about the RCM2300 and its associated Development Kit and Prototyping Board will be found in the printed *RabbitCore RCM2300 Getting Started Manual*, which is also provided on the accompanying CD-ROM in both HTML and Adobe PDF format.

We recommend that any users unfamiliar with Z-World products, or those who will be using the prototyping board for initial evaluation and development, begin with at least a read-through of the *Getting Started* manual.

1.4.2 Additional Reference Information

In addition to the product-specific information contained in the *RabbitCore RCM2300 Getting Started Manual* and the *RabbitCore RCM2300 User's Manual* (this manual), two higher level reference manuals are provided in HTML and PDF form on the accompanying CD-ROM. Advanced users will find these references valuable in developing systems based on the RCM2300 modules:

- *Dynamic C User's Manual*
- *Rabbit 2000 Microprocessor User's Manual*

1.4.3 Using Online Documentation

We provide the bulk of our user and reference documentation in two electronic formats, HTML and Adobe PDF. We do this for several reasons.

We believe that providing all users with our complete library of product and reference manuals is a useful convenience. However, printed manuals are expensive to print, stock, and ship. Rather than include and charge for manuals that every user may not want, or provide only product-specific manuals, we choose to provide our complete documentation and reference library in electronic form with every Development Kit and with our Dynamic C development environment.

NOTE: The most current version of Adobe Acrobat Reader can always be downloaded from Adobe's Web site at <http://www.adobe.com>. We recommend that you use version 4.0 or later.

Providing this documentation in electronic form saves an enormous amount of paper by not printing copies of manuals that users don't need. It reduces the number of outdated manuals we have to discard from stock as well, and it makes providing a complete library of manuals an almost cost-free option. For one-time or infrequent reference, electronic documents are more convenient than printed ones.

1.4.3.1 Finding Online Documents

The online documentation is installed along with Dynamic C, and an icon for the documentation menu is placed on the workstation's desktop. Double-click this icon to reach the menu. If the icon is missing, use your browser to find and load **default.htm** in the **docs** folder, found in the Dynamic C installation folder.

The latest versions of all documents are always available for free, unregistered download from our Web sites as well.

1.4.3.2 Printing Electronic Manuals

We recognize that many users prefer printed manuals for some uses. Users can easily print all or parts of those manuals provided in electronic form. The following guidelines may be helpful:

- Print from the Adobe PDF versions of the files, not the HTML versions.
- Print only the sections you will need to refer to more than once.
- Print manuals overnight, when appropriate, to keep from tying up shared resources during the work day.
- If your printer supports duplex printing, print pages double-sided to save paper and increase convenience.
- If you do not have a suitable printer or do not want to print the manual yourself, most retail copy shops (e.g., Kinkos, AlphaGraphics, CopyMax) will print the manual from the PDF file and bind it for a reasonable charge—about what we would have to charge for a printed and bound manual.

2. HARDWARE REFERENCE

Chapter 2 describes the hardware components and principal hardware subsystems of the RCM2300. Appendix A, “Rabbit-Core RCM2300 Specifications,” provides complete physical and electrical specifications.

2.1 RCM2300 Digital Inputs and Outputs

Figure 1 shows the subsystems designed into the RCM2300.




Figure 1. Rabbit Subsystems

J4

GND			VCC
PC0			PC1
PC2			PC3
TPOUT-			TPOUT+
LNK			PD3
PD4			PD5
/IORD			/IOWR
PE0			PE1
TPIN-			TPIN+
PE4			PE5
ACT			PE7
A3			A2
A1			A0

J5

PA0			PA1
PA2			PA3
PA4			PA5
PA6			PA7
/RES			PB0
PB2			PB3
PB4			PB5
PB7			D7
D6			D5
D4			D3
D2			D1
D0			VBAT
VCC			GND

Note: These pinouts are as seen on the **Bottom Side** of the module.

Fifteen additional connection points are available along one edge of the RCM2300 board. These connection points are 0.030" diameter holes spaced 0.05" apart. Nineteen additional connection points are available at locations J2 and J3. These additional connection points are reserved for future use.

The remaining discussion is focused on the I/O points available on headers J4 and J5 because it is anticipated that most users will not use the through-hole connection points because of their reduced convenience.

Table 1. RabbitCore RCM2300 Pinout Configurations

Pin	Pin Name	Default Use	Alternate Use	Notes
Header J4	1	GND		
	2	VCC		
	3	PC0	Output	TXD
	4	PC1	Input	RXD
	5	PC2	Output	TXC
	6	PC3	Input	RXC
	7	PC6	Output	TXA
	8	PC7	Input	RXA
	9	PE2	Bidirectional I/O	I/O control
	10	PD3	Bitwise or parallel programmable I/O	
	11	PD4		ATXB output
	12	PD5		ARXB input
	13	/IORD	Input (I/O read strobe)	
	14	/IOWR	Output (I/O write strobe)	
	15	PE0	Bitwise or parallel programmable I/O	I0 control or INT0A input
	16	PE1		I1 control or INT1A input
	17	SMODE1	Startup mode bit input	Can only be used as general inputs <i>after</i> the startup mode op-code has been read following boot-up
	18	SMODE0	Startup mode bit input	
	19	PE4	Bitwise or parallel programmable I/O	I4 control or INT0B input
	20	PE5		I5 control or INT1B input
	21	STATUS	Low on first op-code fetch of instruction	Output
	22	PE7	Bitwise or parallel programmable I/O	I7 control or slave port chip select /SCS
	23–26	A[3:0]		Rabbit 2000 address bus

Table 1. RabbitCore RCM2300 Pinout Configurations (continued)

Pin		Pin Name	Default Use	Alternate Use	Notes
Header J5	1–8	PA[0:7]	Bytewise programmable parallel I/O	Slave port data bus SD0–SD7	
	9	/RESET	Reset output	Reset input	This weak output can be driven externally
	10	PB0	Input	Serial port clock CLKB input or output	
	11	PB2	Input	Slave port write /SWR	
	12	PB3	Input	Slave port read /SRD	
	13	PB4	Input	SA0	Slave port address lines
	14	PB5	Input	SA1	
	15	PB7	Output	Slave port attention line /SLAVEATTN	
	16–23	D[7:0]	Input/Output		Rabbit 2000 data bus
	24	VBAT	3 V battery input		
	25	VCC			
	26	GND			

2.1.1 Dedicated Inputs

PB0 is a general CMOS input when the Rabbit 2000 is either not using Serial Port B or is using Serial Port B in an asynchronous mode. Four other general CMOS input-only pins are located on PB2–PB5. These pins can also be used for the slave port in master/slave communication between two processors. PB2 and PB3 are slave write and slave read strobes, while PB4 and PB5 serve as slave address lines SA0 and SA1, and are used to access the slave registers. PC1, PC3, and PC7 are general CMOS inputs only. These pins can instead be selectively enabled to serve as the serial data inputs for Serial Ports D, C, and A.

SMODE0 and SMODE1 are read at start-up, and set the mode whereby instructions are fetched. Thereafter the user may use and read these pins as inputs by reading the Slave Port Control Register.

NOTE: Exercise care so that the SMODE0 and SMODE1 pins revert to the correct startup code when a reset occurs.

2.1.2 Dedicated Outputs

One of the general CMOS output-only pins is located on PB7. PB7 can also be used with the slave port as the /SLAVEATTN output. This configuration signifies that the slave is requesting attention from the master. PC0, PC2, and PC6 are also output-only pins; alternatively, they can serve as the serial data outputs for Serial Ports D, C, and A.

The STATUS pin goes low by default after the first op-code fetch of an instruction cycle. The STATUS pin may be programmed as a separate output by changing the Rabbit 2000's Global Output Control Register.

2.1.3 Memory I/O Interface

Four of the Rabbit 2000 address lines (A0–A3) and all the data lines (D0–D7) are available. I/O write (/IOWR) and I/O read (/IORD) are also available for interfacing to external devices.

2.1.4 Other Inputs and Outputs

As shown in Table 1, pins PA0–PA7 can be used to allow the Rabbit 2000 to be a slave to another processor. The slave port also uses PB2–PB5, PB7, and PE7.

PE0, PE1, PE4, and PE5 can be used for up to two external interrupts. PB0 can be used to access the clock on Serial Port B of the Rabbit microprocessor. PD4 can be programmed to be a serial output for Serial Port B. PD5 can be used as a serial input by Serial Port B.

2.2 Serial Communication

The RCM2300 board does not have an RS-232 or an RS-485 transceiver directly on the board. However, an RS-232 or RS-485 interface may be incorporated on the board the RCM2300 is mounted on. For example, the Prototyping Board supports a standard RS-232 transceiver chip.

2.2.1 Serial Ports

There are four serial ports designated as Serial Ports A, B, C, and D. All four serial ports can sustain their operation in an asynchronous mode up to the baud rate of the system clock divided by 64. The maximum burst rate for an asynchronous byte can be as high as the system clock divided by 32. An asynchronous port can handle 7 or 8 data bits. A 9th bit address scheme, where an additional bit is sent to mark the first byte of a message, is also supported.

Serial Ports A and B can also be operated in the clocked serial mode. In this mode, a clock line synchronously clocks the data in or out. Either of the two communicating devices can supply the clock. When the Rabbit 2000 provides the clock, the sustained baud rate can be up to the system clock frequency divided by 8, or 2.76 Mbps for a 22.1 MHz clock speed. The maximum burst rate for a byte can be as high as the system clock divided by 4.

Serial Port A's clock pin is available only on the programming port, and so is likely to be inconvenient to interface with.

2.2.2 Programming Port

Serial Port A has special features that allow it to cold-boot the system after reset. Serial Port A is also the port that is used for software development under Dynamic C.

The RCM2300 has a 10-pin program header labeled J1. The Rabbit 2000 startup-mode pins (SMODE0, SMODE1) are presented to the programming port so that an externally connected device can force the RCM2300 to start up in an external bootstrap mode. The *Rabbit 2000 Microprocessor User's Manual* provides more information about the bootstrap mode.

The programming port is used to start the RCM2300 in a mode where it will download a program from the port and then execute the program. The programming port transmits information to and from a PC while a program is being debugged in-circuit.

The RCM2300 can be reset from the programming port via the /RES_IN line.

The Rabbit 2000 status pin is also presented to the programming port. The status pin is an output that can be used to send a general digital signal.

The clock line for Serial Port A is presented to the programming port, which makes synchronous serial communication possible.

All the programming port pins, except the Serial Port A clock line, are duplicated on the 26-pin headers.

2.2.2.1 Alternate Uses of the Programming Port

The programming port may also be used as an application port with the **DIAG** connector on the programming cable.

All three clocked Serial Port A signals are available for use as

- a synchronous serial port
- an asynchronous serial port, with the clock line usable as a general CMOS input
- two general CMOS inputs and one general CMOS output.

Two startup mode pins, SMODE0 and SMODE1, are available as general CMOS inputs after they are read during the initial boot-up. The logic state of these two pins is very important in determining the startup procedure after a reset.

/RES_IN is an external input used to reset the Rabbit 2000 microprocessor.

The status pin may also be used as a general CMOS output.

See Appendix D, “Programming Cable,” for more information.

2.3 Other Hardware

2.3.1 Clock Doubler

The RCM2300 takes advantage of the Rabbit 2000 microprocessor's internal clock doubler. A built-in clock doubler allows half-frequency crystals to be used to reduce radiated emissions. The 22.1 MHz frequency is generated using an 11.0592 MHz crystal. The clock doubler is disabled automatically in the BIOS for crystals with a frequency above 12.9 MHz.

The clock doubler may be disabled if 22.1 MHz clock speeds are not required. Disabling the Rabbit 2000 microprocessor's internal clock doubler will reduce power consumption and further reduce radiated emissions. The clock doubler is disabled with a simple change to the BIOS as described below.

1. Open the BIOS source code file, **RABBITBIOS.C** in the **BIOS** directory.
2. Change the line

```
#define CLOCK_DOUBLED 1 // set to 1 to double the clock if XTAL<=12.9MHz,  
to read as follows.
```

```
#define CLOCK_DOUBLED 0 // set to 1 to double the clock if XTAL<=12.9MHz,
```

3. Save the change using **File > Save**.

2.3.2 Spectrum Spreader

RCM2300 boards with a Rabbit 2000 microprocessor labeled IQ4T or higher have a spectrum spreader, which helps to mitigate EMI problems. By default, the spectrum spreader is on automatically for these boards when used with Dynamic C 7.30 or later versions, but the spectrum spreader may also be turned off or set to a stronger setting. The means for doing so is through a simple change to the following BIOS line in a way that is similar to the clock doubler described above.

```
#define ENABLE_SPREADER 1 // Set to 0 to disable spectrum spreader  
// 1 to enable normal spreading, or  
// 2 to enable strong spreading.
```

NOTE: The strong spectrum-spreading setting is unnecessary for the RCM2300.

There is no spectrum spreader functionality for RCM2300 boards with Rabbit 2000 chips labeled IQ3T or earlier, or with a version of Dynamic C prior to 7.30.

2.4 Memory

2.4.1 SRAM

The RCM2300 is designed to accept 128K of SRAM packaged in an SOIC case.

2.4.2 Flash EPROM

The RCM2300 is also designed to accept 128K to 512K of flash EPROM packaged in a TSOP case.

NOTE: Z-World recommends that any customer applications should not be constrained by the sector size of the flash EPROM since it may be necessary to change the sector size in the future.

Writing to arbitrary flash memory addresses at run time is also discouraged. Instead, define a “user block” area to store persistent data. The functions **writeUserBlock** and **readUserBlock** are provided for this.

A Flash Memory Bank Select jumper configuration option based on 0 Ω surface-mounted resistors exists at JP2. This option, used in conjunction with some configuration macros, allows Dynamic C to compile two different co-resident programs for the upper and lower halves of the 256K flash in such a way that both programs start at logical address 0000. This is useful for applications that require a resident download manager and a separate downloaded program. See Technical Note 218, *Implementing a Serial Download Manager for a 256K Flash*, for details.

NOTE: Only the Normal Mode, which corresponds to using the full code space, is supported at the present time.

2.4.3 Dynamic C BIOS Source Files

The Dynamic C BIOS source files handle different standard RAM and flash EPROM sizes automatically.

3. SOFTWARE REFERENCE

Dynamic C is an integrated development system for writing embedded software. It runs on an IBM-compatible PC and is designed for use with Z-World controllers and other controllers based on the Rabbit microprocessor. Chapter 3 provides the libraries, function calls, and sample programs related to the RCM2300.

3.1 More About Dynamic C

Dynamic C has been in use worldwide since 1989. It is specially designed for programming embedded systems, and features quick compile and interactive debugging in the real environment. A complete reference guide to Dynamic C is contained in the *Dynamic C User's Manual*.

You have a choice of doing your software development in the flash memory or in the static RAM included on the RCM2300. The advantage of working in RAM is to save wear on the flash memory, which is limited to about 100,000 write cycles.

NOTE: An application can be developed in RAM, but cannot run standalone from RAM after the programming cable is disconnected. All standalone applications can only run from flash memory.

NOTE: Do not depend on the flash memory sector size or type. Due to the volatility of the flash memory market, the RCM2300 and Dynamic C were designed to accommodate flash devices with various sector sizes.

The disadvantage of using flash memory for debug is that interrupts must be disabled for approximately 5 ms whenever a break point is set in the program. This can crash fast interrupt routines that are running while you stop at a break point or single-step the program. Flash memory or RAM is selected on the **Options > Compiler** menu.

Dynamic C provides a number of debugging features. You can single-step your program, either in C, statement by statement, or in assembly language, instruction by instruction. You can set break points, where the program will stop, on any statement. You can evaluate watch expressions. A watch expression is any C expression that can be evaluated in the context of the program. If the program is at a break point, a watch expression can view any expression using local or external variables. If a periodic call to `runwatch()` is included in your program, you will be able to evaluate watch expressions by hitting **<Ctrl-U>** without stopping the program.

3.2 Programming Cable

The RCM2300 is automatically in program mode when the **PROG** connector on the programming cable is attached, and is automatically in run mode when no programming cable is attached.

The **DIAG** connector of the programming cable may be used on header J1 of the RCM2300 with the board operating in the run mode. This allows the programming port to be used as an application port. See Appendix D, “Programming Cable,” for more information.




Figure 3. Switching Between Program Mode and Run Mode

3.2.1 Changing from Program Mode to Run Mode

1. Disconnect the programming cable from header J1 of the RCM2300.
2. Reset the RCM2300. You may do this as explained in Figure 3.

The RCM2300 is now ready to operate in the run mode.


3.2.2 Changing from Run Mode to Program Mode

1. Attach the programming cable to header J1 on the RCM2300.
2. Reset the RCM2300 series. You may do this as explained in Figure 3.

The RCM2300 is now ready to operate in the program mode.

3.3 Dynamic C Libraries

With Dynamic C running, click **File > Open**, and select **Lib**. The following list of Dynamic C libraries will be displayed.



There is no unique library that is specific to the RCM2300. The functions in the above libraries are described in the *Dynamic C User's Manual*.

3.3.1 I/O

The RCM2300 was designed to interface with other systems, and so there are no drivers written specifically for the I/O. The general Dynamic C read and write functions allow you to customize the parallel I/O to meet your specific needs. For example, use

```
WrPortI(PEDDR, &PEDDRShadow, 0x00);
```

to set all the Port E bits as inputs, or use

```
WrPortI(PEDDR, &PEDDRShadow, 0xFF);
```

to set all the Port E bits as outputs.

The sample programs in the Dynamic C **SAMPLES/RCM2300** directory provide further examples.

These functions are provided for convenience, not speed. User code should be written in assembly language when speed is important.

3.3.2 Serial Communication Drivers

The Prototyping Board has room for an RS-232 chip. Dynamic C has two libraries to support serial communication: **RS232.LIB** provides a set of circular-buffer-based functions, and **PACKET.LIB** provides packet-based support. Packets can be delimited by time gap, 9th bit detection, or special-character detection.

Both the packet-based and the circular-buffer-based routines are available in blocking and nonblocking (cofunction) flavors. See the *Dynamic C User's Manual* and Technical Note 213, *Rabbit 2000 Serial Port Software*, for more details on serial communication.

3.3.2.1 External Interrupts


The Rabbit 2000 microprocessor has four external interrupt inputs on Parallel Port E, which is accessed through pins PE0, PE1, PE4, and PE5 on header J4. These pins may be used either as I/O ports or as external interrupt inputs.

Earlier versions of the Rabbit 2000 microprocessor labeled ***IQ1T*** or ***IQ2T*** would occasionally lose an interrupt request when one of the interrupt inputs was used as a pulse counter. See Technical Note 301, ***Rabbit 2000 Microprocessor Interrupt Problem***, for further information on how to work around this problem if you purchased your RCM2200 before July, 2002, and the Rabbit 2000 microprocessor is labeled ***IQ1T*** or ***IQ2T***.

NOTE: Interrupts on RCM2000 series RabbitCore modules sold after July, 2002, work correctly and do not need this workaround.


3.4 Sample Programs

Sample programs are provided in the Dynamic C **samples** folder, which is shown below.



The various folders contain specific sample programs that illustrate the use of the corresponding Dynamic C libraries. For example, the sample program **PONG.C** demonstrates the output to the Dynamic C **STDIO** window.

The sample programs in the Dynamic C **SAMPLES/RCM2300** directory demonstrate the basic operation of the RCM2300.



Follow the instructions included with the sample program to connect the RCM2300 and the other hardware identified in the instructions.

To run a sample program, open it with the **File** menu (if it is not still open), compile it using the **Compile** menu, and then run it by selecting **Run** in the **Run** menu. The RCM2300 must be in Program Mode (see Section 3.2, “Programming Cable”) and must be connected to a PC using the programming cable.

More complete information on Dynamic C is provided in the *Dynamic C User's Manual*.

3.5 Upgrading Dynamic C

Dynamic C patches that focus on bug fixes are available from time to time. Check the Web sites

- www.zworld.com/support/

or

- www.rabbitsemiconductor.com/support/

for the latest patches, workarounds, and bug fixes.

The default installation of a patch or bug fix is to install the file in a directory (folder) different from that of the original Dynamic C installation. Z-World recommends using a different directory so that you can verify the operation of the patch without overwriting the existing Dynamic C installation. If you have made any changes to the BIOS or to libraries, or if you have programs in the old directory (folder), make these same changes to the BIOS or libraries in the new directory containing the patch. Do **not** simply copy over an entire file since you may overwrite a bug fix; of course, you may copy over any programs you have written. Once you are sure the new patch works entirely to your satisfaction, you may retire the existing installation, but keep it available to handle legacy applications.

3.5.1 Upgrades

Dynamic C installations are designed for use with the board they are included with, and are included at no charge as part of our low-cost kits. Dynamic C is a complete software development system, but does not include all the Dynamic C features. Z-World also offers add-on Dynamic C modules containing the popular μ C/OS-II real-time operating system, as well as PPP, Advanced Encryption Standard (AES), and other select libraries. In addition to the Web-based technical support included at no extra charge, a one-year telephone-based technical support module is also available for purchase.



APPENDIX A. RABBITCORE RCM2300 SPECIFICATIONS

Appendix A provides the specifications for the RCM2300, and describes the conformal coating.

A.1 Electrical and Mechanical Characteristics

Figure A-1 shows the mechanical dimensions for the RCM2300.




Figure A-1. RabbitCore RCM2300 Dimensions

It is recommended that you allow for an “exclusion zone” of 0.04" (1 mm) around the RCM2300 in all directions when the RCM2300 is incorporated into an assembly that includes other printed circuit boards. This “exclusion zone” that you keep free of other components and boards will allow for sufficient air flow, and will help to minimize any electrical or EMI interference between adjacent boards. An “exclusion zone” of 0.12" (3 mm) is recommended below the RCM2300 when the RCM2300 is plugged into another assembly using the shortest connectors for headers J4 and J5. Figure A-2 shows this “exclusion zone.”




Figure A-2. RCM2300 “Exclusion Zone”

Table A-1 lists the electrical, mechanical, and environmental specifications for the RCM2300.

Table A-1. RabbitCore RCM2300 Specifications

Parameter	Specification
Microprocessor	Rabbit 2000® at 22.1 MHz
Flash Memory	256K
SRAM	128K
Backup Battery	Connection for user-supplied backup battery (to support RTC and SRAM)
General-Purpose I/O*	29 parallel I/O lines grouped in five 8-bit ports (shared with serial ports): <ul style="list-style-type: none"> • 17 configurable I/O • 8 fixed inputs • 4 fixed outputs
Additional Inputs	2 startup mode, reset
Additional Outputs	Status, reset
Memory I/O Interface	4 address lines, 8 data lines, I/O read/write (extra address and buffer enable via separate connections)
Serial Ports	Four 5 V CMOS-compatible ports. Two ports are configurable as clocked ports, one is a dedicated RS-232 programming port.
Serial Rate	Max. burst rate = CLK/32 Max. sustained rate = CLK/64
Slave Interface	A slave port allows the RCM2300 to be used as an intelligent peripheral device slaved to a master processor, which may either be another Rabbit 2000 or any other type of processor
Real-Time Clock	Yes
Timers	Five 8-bit timers cascable in pairs, one 10-bit timer with 2 match registers that each have an interrupt
Watchdog/Supervisor	Yes
Power	4.75 V to 5.25 V DC, 108 mA
Operating Temperature	–40°C to +85°C
Humidity	5% to 95%, noncondensing
Connectors	Two IDC headers 2 × 13, 2 mm pitch
Board Size	1.15" × 1.60" × 0.48" (29 mm × 41 mm × 12 mm)

* 15 additional I/O are available via less convenient 0.03" diameter through-hole connection points

A.1.1 Headers

The RCM2300 uses headers at J4 and J5 for physical connection to other boards. J4 and J5 are 2×13 SMT headers with a 2 mm pin spacing. J1, the programming port, is a 2×5 header with a 2 mm pin spacing.

Figure A-3 shows the footprint of another board that the RCM2300 would be plugged into. These values are relative to the header connectors.




Figure A-3. User Board Footprint for RabbitCore RCM2300

A.1.2 Physical Mounting

An 9/32" or 1/4" (7 mm) metal standoff with insulating washers and a 4-40 screw is recommended to attach the RCM2300 to a user board at the hole position shown in Figure A-3.

A.2 Bus Loading

You must pay careful attention to bus loading when designing an interface to the RCM2300. This section provides bus loading information for external devices.

Table A-2 lists the capacitance for the various Rabbit 2000 I/O ports with SRAM and flash memory connected.

Table A-2. Capacitance of Rabbit 2000 I/O Ports with External Memory

I/O Ports	Input Capacitance (pF)	Output Capacitance (pF)
Parallel Ports A to E	12	14
Data Lines D0–D7	30	32
Address Lines A0–A12	—	32

Table A-3 lists the external capacitive bus loading for the various Rabbit 2000 output ports. Be sure to add the loads for the devices you are using in your system and verify that they do not exceed the values in Table A-3.

Table A-3. External Capacitive Bus Loading -40°C to +85°C

Output Port	Clock Speed (MHz)	Maximum External Capacitive Loading (pF)
A[4:1] D[7:1]	22.1	50
A[4:1] D[7:1]	22.1	100 for 55 ns flash
A0 D0	22.1	100
PD[3:0]	22.1	100
PA[7:0] PB[7,6] PC[6,2,0] PD[7:0] PE[7:0]	22.1	90
All data, address, and I/O lines with clock doubler disabled	11.06	100

The values from the table above are derived using 55 ns (flash memory) and 70 ns (SRAM) memory access times. External capacitive loading can be improved by 10 pF for commercial temperature ranges, but do not exceed 100 pF. See the AC timing specifications in the *Rabbit 2000 Microprocessor Users Manual* for more information.

Figure A-4 shows a typical timing diagram for the Rabbit 2000 microprocessor external memory read and write cycles.




Figure A-4. Memory Read and Write Cycles

T_{adr} is the time required for the address output to reach 0.8 V. This time depends on the bus loading. T_{setup} is the data setup time relative to the clock. T_{setup} is specified from 30%/70% of the V_{DD} voltage level.

Table A-4 lists the parameters shown in these figures and provides minimum or measured values.

Table A-4. Memory and External I/O Read/Write Parameters

Parameter		Description	Value	
Read Parameters	T_{adr}	Time from CPU clock rising edge to address valid	Max.	7 ns @ 20 pF, 5 V (10 ns @ 3.3 V) 14 ns @ 70 pF, 5 V (19 ns @ 3.3 V)
	T_{setup}	Data read setup time	Min.	2 ns @ 5 V (3 ns @ 3.3 V)
	T_{hold}	Data read hold time	Min.	0 ns
Write Parameters	T_{adr}	Time from CPU clock rising edge to address valid	Max.	7 ns @ 20 pF, 5 V (10 ns @ 3.3 V) 14 ns @ 70 pF, 5 V (19 ns @ 3.3 V)
	T_{hold}	Data write hold time from /WEx or /IOWR	Min.	½ CPU clock cycle

A.3 Rabbit 2000 DC Characteristics

Table A-5 outlines the DC characteristics for the Rabbit 2000 at 5.0 V over the recommended operating temperature range from $T_a = -40^\circ\text{C}$ to $+85^\circ\text{C}$, $V_{\text{DD}} = 4.5 \text{ V}$ to 5.5 V .

Table A-5. 5.0 Volt DC Characteristics

Symbol	Parameter	Test Conditions	Min	Typ	Max	Units
I_{IH}	Input Leakage High	$V_{\text{IN}} = V_{\text{DD}}$, $V_{\text{DD}} = 5.5 \text{ V}$			10	μA
I_{IL}	Input Leakage Low (no pull-up)	$V_{\text{IN}} = V_{\text{SS}}$, $V_{\text{DD}} = 5.5 \text{ V}$	-10			μA
I_{OZ}	Output Leakage (no pull-up)	$V_{\text{IN}} = V_{\text{DD}}$ or V_{SS} , $V_{\text{DD}} = 5.5 \text{ V}$	-10		10	μA
V_{IL}	CMOS Input Low Voltage				$0.3 \times V_{\text{DD}}$	V
V_{IH}	CMOS Input High Voltage		$0.7 \times V_{\text{DD}}$			V
V_{T}	CMOS Switching Threshold	$V_{\text{DD}} = 5.0 \text{ V}$, 25°C		2.4		V
V_{OL}	CMOS Output Low Voltage	$I_{\text{OL}} = \text{See Table A-6 (sinking)}$ $V_{\text{DD}} = 4.5 \text{ V}$		0.2	0.4	V
V_{OH}	CMOS Output High Voltage	$I_{\text{OH}} = \text{See Table A-6 (sourcing)}$ $V_{\text{DD}} = 4.5 \text{ V}$	$0.7 \times V_{\text{DD}}$	4.2		V

A.4 I/O Buffer Sourcing and Sinking Limit

Unless otherwise specified, the Rabbit I/O buffers are capable of sourcing and sinking 8 mA of current per pin at full AC switching speed. Full AC switching assumes a 22.1 MHz CPU clock and capacitive loading on address and data lines of less than 100 pF per pin. Address pin A0 and data pin D0 are rated at 16 mA each. Pins A1–A4 and D1–D7 are each rated at 8 mA. The absolute maximum operating voltage on all I/O is $V_{DD} + 0.5$ V, or 5.5 V.

Table A-6 shows the AC and DC output drive limits of the parallel I/O buffers when the Rabbit 2000 is used in the RCM2300.

Table A-6. I/O Buffer Sourcing and Sinking Capability

Pin Name	Output Drive	
	Sourcing [*] /Sinking [†] Limits (mA)	
Output Port Name	Full AC Switching SRC/SNK	Maximum [‡] DC Output Drive SRC/SNK
PA [7:0]	8/8	12/12
PB [7, 1, 0]	8/8	12/12
PC [6, 2, 0]	8/8	12/12
PD [7:4]	8/8	12/12
PD [3:0] ^{**}	16/16	25/25
PE [7:0]	8/8	12/12

* The maximum DC sourcing current for I/O buffers between V_{DD} pins is 112 mA.

† The maximum DC sinking current for I/O buffers between V_{SS} pins is 150 mA.

‡ The maximum DC output drive on I/O buffers must be adjusted to take into consideration the current demands made by AC switching outputs, capacitive loading on switching outputs, and switching voltage.

The current drawn by all switching and nonswitching I/O must not exceed the limits specified in the first two footnotes.

** The combined sourcing from Port D [7:0] may need to be adjusted so as not to exceed the 112 mA sourcing limit requirement specified in the first footnote.

The area around the crystal oscillator has had the Dow Corning silicone-based 1-2620 conformal coating applied. The conformally coated area is shown in Figure A-5. The conformal coating protects these high-impedance circuits from the effects of moisture and contaminants over time.



NOTE: For more information on conformal coatings, refer to Rabbit Semiconductor Technical Note 303, *Conformal Coatings*.

A.6 Jumper Configurations

Figure A-6 shows the header locations used to configure the various RCM2300 options via jumpers.




Figure A-6. Location of RCM2300 Configurable Positions

Table A-7 lists the configuration options.

Table A-7. RCM2300 Jumper Configurations

Header	Description	Pins Connected		Factory Default
JP1	Flash Memory Size	1–2	128K/256K	×
		2–3	512K	
JP2	Flash Memory Bank Select	1–2	Normal Mode	×
		2–3	Bank Mode	

NOTE: The jumper connections are made using 0 Ω surface-mounted resistors.



APPENDIX B. PROTOTYPING BOARD

Appendix B describes the features and accessories of the Prototyping Board, and explains the use of the Prototyping Board to demonstrate the RCM2300 and to build prototypes of your own circuits.

Figure B-1 shows the mechanical dimensions and layout for the RCM2300 Prototyping Board.




Figure B-1. RCM2300 Prototyping Board Dimensions

Table B-1 lists the electrical, mechanical, and environmental specifications for the Prototyping Board.

Table B-1. RCM2300 Prototyping Board Specifications

Parameter	Specification
Board Size	4.25" × 5.25" × 1.00" (108 mm × 133 mm × 25 mm)
Operating Temperature	−40°C to +70°C
Humidity	5% to 95%, noncondensing
Input Voltage	7.5 V to 25 V DC
Maximum Current Draw (including user-added circuits)	1 A at 12 V and 25°C, 0.7 A at 12 V and 70°C
Prototyping Area	2.4" × 4.0" (61 mm × 102 mm) throughhole, 0.1" spacing, additional space for SMT components
Corner Standoffs/Spacers	4, accept 6-32 × 3/8 screws

B.2 Power Supply

The RCM2300 requires a regulated $5\text{ V} \pm 0.25\text{ V}$ DC power source to operate. Depending on the amount of current required by the application, different regulators can be used to supply this voltage.

The Prototyping Board has an onboard 7805 or equivalent linear regulator that is easy to use. Its major drawback is its inefficiency, which is directly proportional to the voltage drop across it. The voltage drop creates heat and wastes power.

A switching power supply may be used in applications where better efficiency is desirable. The LM2575 is an example of an easy-to-use switcher. This part greatly reduces the heat dissipation of the regulator. The drawback in using a switcher is the increased cost.

The Prototyping Board itself is protected against reverse polarity by a Shottky diode at D2 as shown in Figure B-2.




Figure B-2. Prototyping Board Power Supply

B.3 Using the Prototyping Board

The Prototyping Board is actually both a demonstration board and a prototyping board. As a demonstration board, it can be used to demonstrate the functionality of the RCM2300 right out of the box without any modifications to either board. There are no jumpers or dip switches to configure or misconfigure on the Prototyping Board so that the initial setup is very straightforward.

The Prototyping Board comes with the basic components necessary to demonstrate the operation of the RCM2300. Two LEDs (DS2 and DS3) are connected to PE1 and PE7, and two switches (S2 and S3) are connected to PB2 and PB3 to demonstrate the interface to the Rabbit 2000 microprocessor. Reset switch S1 is the hardware reset for the RCM2300.

To maximize the availability of RCM2300 resources, the demonstration hardware (LEDs and switches) on the Prototyping Board may be disconnected. This is done by cutting the traces below the silk-screen outline of header JP1 on the bottom side of the Prototyping Board. Figure B-3 shows the four places where cuts should be made. An exacto knife would work nicely to cut the traces. Alternatively, a small standard screwdriver may be carefully and forcefully used to wipe through the PCB traces.




Figure B-3. Where to Cut Traces to Permanently Disable Demonstration Hardware on Prototyping Board

The power LED (PWR) and the RESET switch remain connected. Jumpers across the appropriate pins on header JP1 can be used to reconnect specific demonstration hardware later if needed.

Table B-2. Prototyping Board Jumper Settings

Header JP1	
Pins	Description
1–2	PE1 to LED DS2
3–4	PE7 to LED DS3
5–6	PB2 to Switch S2
7–8	PB3 to Switch S3

Note that the pinout at location JP1 on the bottom side of the Prototyping Board (shown in Figure B-3) is a mirror image of the top-side pinout.

The Prototyping Board provides the user with RCM2300 connection points brought out conveniently to labeled points at headers J7 and J8 on the Prototyping Board. Small to medium circuits can be prototyped using point-to-point wiring with 20 to 30 AWG wire between the prototyping area and the holes at locations J7 and J8. The holes are spaced at 0.1" (2.5 mm),

and 40-pin headers or sockets may be installed at J7 and J8. The pinouts for locations J7 and J8, which correspond to headers J1 and J2, are shown in Figure B-4.




Figure B-4. RCM2300 Prototyping Board Pinout (Top View)

The small holes are also provided for surface-mounted components that may be installed to the right of the prototyping area.

There is a 2.4" × 4" through-hole prototyping space available on the Prototyping Board. VCC and GND traces run along the edge of the Prototyping Board for easy access. A GND pad is also provided at the lower right for alligator clips or probes.




Figure B-5. VCC and GND Traces Along Edge of Prototyping Board

B.3.1 Adding Other Components

There is room on the Prototyping Board for a user-supplied RS-232 transceiver chip at location U2 and a 10-pin header for serial interfacing to external devices at location J6. A Maxim MAX232 transceiver is recommended. When adding the MAX232 transceiver at position U2, you must also add 100 nF charge storage capacitors at positions C3–C7 as shown in Figure B-6.




Figure B-6. Location for User-Supplied RS-232 Transceiver and Charge Storage Capacitors on Back Side of Prototyping Board

NOTE: The board that is supplied with the DeviceMate Development Kit already has the RS-232 chip and the storage capacitors installed, and is called the DeviceMate Demonstration Board.

There are two sets of pads at the lower right corner of the Prototyping Board that can be used for surface-mount prototyping SOIC devices. The silk screen layout separates the rows into six 16-pin devices (three on each side). However, there are pads between the silk screen layouts giving the user two 52-pin (2×26) SOIC layouts with 50 mil pin spacing. There are six sets of pads that can be used for 3- to 6-pin SOT23 packages. There are also 60 sets of pads that can be used for SMT resistors and capacitors in an 0805 SMT package. Each component has every one of its pin pads connected to a hole in which a 30 AWG wire can be soldered (standard wire wrap wire can be soldered in for point-to-point wiring on the Prototyping Board). Because the traces are very thin, carefully determine which set of holes is connected to which surface-mount pad.

There is also a space above the space for the RS-232 transceiver that can accommodate a large surface-mounted SOIC component.

B.3.2 Attach Modules to Prototyping Board

Turn the RCM2300 module so that the Rabbit logo and the mounting hole are as shown in Figure B-7 below. Align the module headers J4 and J5 into sockets J1 and J2 (the **MASTER** slots) on the Prototyping Board. Press the module's pins firmly into the Prototyping Board headers.




Figure B-7. Install the RCM2300 on the Prototyping Board

NOTE: It is important that you line up the pins of the module headers exactly with the corresponding pins on the Prototyping Board. The header pins may become bent or damaged if the pin alignment is offset, and the module will not work. Permanent electrical damage to the module may also result if a misaligned module is powered up.

With the RCM2300 plugged into the **MASTER** slots, it can act as the “master” relative to another RabbitCore RCM2200 or RCM2300 plugged into the **SLAVE** slots, which acts as the “slave.”

This master/slave relationship is *not* used in the DeviceMate Development Kit where the “target” RCM2300 is plugged into the **MASTER** slots, and the RCM2200, which is used as the DeviceMate hardware platform, is plugged into the **SLAVE** slots. The Prototyping and Demonstration Board serves only as a means to connect the two RabbitCore modules together to demonstrate the DeviceMate software features in Dynamic C.

APPENDIX C. POWER SUPPLY

Appendix C provides information on the current requirements of the RCM2300, and some background on the chip select circuit used in power management.

C.1 Power Supplies

The RCM2300 requires a regulated $5\text{ V} \pm 0.25\text{ V}$ DC power source. The RabbitCore design presumes that the voltage regulator is on the user board, and that the power is made available to the RabbitCore board through headers J4 and J5.

An RCM2300 with no loading at the outputs operating at 22.1 MHz typically draws 108 mA. The RCM2300 will consume an additional 10 mA when the programming cable is used to connect J1 to a PC.

C.2 Battery Backup

The RCM2300 does not have a factory-installed battery, but there is provision for a customer-supplied battery to back up SRAM and keep the internal Rabbit 2000 real-time clock running.

Header J5, shown in Figure C-1, allows access to an external battery. This header makes it possible to connect an external 3 V power supply.




Figure C-1. External Battery Connections at Header J5

The RCM2300 has another battery option available. A customer-installed BR2577A/GA backup battery can be soldered right on the RCM2300 as shown in Figure C-2. The negative battery connection is to the pin 3 hole in the area corresponding to header area J3.




Figure C-2. Installing Onboard Backup Battery on RCM2300

NOTE: Installing an onboard backup battery directly on the RCM2300 will prevent you from adding a through-hole connector at position J3 pin 3 on the other side of the RCM2300.

Alternatively, you may wish to add a 2-pin connector with a 2 mm pitch for hooking up to an external backup battery as shown in Figure C-3.




Figure C-3. Installing Optional Battery Connector on RCM2300

A lithium battery with a nominal voltage of 3 V and a minimum capacity of 165 mA·h is recommended. A lithium battery is strongly recommended because of its nearly constant nominal voltage over most of its life.

The drain on the battery by the RCM2300 is typically 16 μ A when no other power is supplied. If a 950 mA·h battery is used, the battery can last more than 6 years:

$$\frac{950 \text{ mA}\cdot\text{h}}{16 \text{ }\mu\text{A}} = 6.8 \text{ years.}$$

The actual life in your application will depend on the current drawn by components not on the RCM2300 and the storage capacity of the battery. Note that the shelf life of a lithium battery is ultimately 10 years.

C.2.1 Battery Backup Circuits

The battery-backup circuit serves three purposes:

- It reduces the battery voltage to the SRAM and to the real-time clock, thereby limiting the current consumed by the real-time clock and lengthening the battery life.
- It ensures that current can flow only *out* of the battery to prevent charging the battery.
- A voltage, VOSC, is supplied to U6, which keeps the 32.768 kHz oscillator working when the voltage begins to drop.

VRAM and Vcc are nearly equal (<100 mV, typically 10 mV) when power is supplied to the RCM2300.

Figure C-4 shows the RCM2300 battery-backup circuit.




Figure C-4. RCM2300 Battery-Backup Circuit

C.2.2 Reset Generator

The RCM2300 uses a reset generator, U1, to reset the Rabbit 2000 microprocessor when the voltage drops below the voltage necessary for reliable operation. The reset occurs between 4.50 V and 4.75 V, typically 4.63 V. The RCM2300 has a reset output, pin 9 on header J5. This reset output can be sensed externally. The output can also be overridden and forced into any state by using a circuit capable of providing 5 mA of output current.

C.3 Chip Select Circuit

The RCM2300 has provision for battery backup, which kicks in to keep VRAM from dropping below 2 V.

When the RCM2300 is not powered, the battery keeps the SRAM memory contents and the real-time clock (RTC) going. The SRAM has a powerdown mode that greatly reduces power consumption. This powerdown mode is activated by raising the chip select (CS) signal line. Normally the SRAM requires V_{cc} to operate. However, only 2 V is required for data retention in powerdown mode. Thus, when power is removed from the circuit, the battery voltage needs to be provided to both the SRAM power pin and to the CS signal line. The CS control switch accomplishes this task for the CS signal line.

Figure C-5 shows a schematic of the chip select control switch.




Figure C-5. Chip Select Control Switch

In a powered-up condition, the CS control switch must allow the processor's chip select signal /CS1 to control the SRAM's CS signal /CSRAM. So, with power applied, /CSRAM must be the same signal as /CS1, and with power removed, /CSRAM must be held high (but only needs to be as high as the battery voltage). Q3 and Q4 are MOSFET transistors with opposing polarity. They are both turned on when power is applied to the circuit. They allow the CS signal to pass from the processor to the SRAM so that the processor can periodically access the SRAM. When power is removed from the circuit, the transistors will turn off and isolate /CSRAM from the processor. The isolated /CSRAM line has a 100 k Ω pullup resistor to VRAM (R28). This pullup resistor keeps /CSRAM at the VRAM voltage level (which under no power condition is the backup battery's regulated voltage at a little more than 2 V).

Transistors Q3 and Q4 are of opposite polarity so that a rail-to-rail voltages can be passed. When the /CS1 voltage is low, Q3 will conduct. When the /CS1 voltage is high, Q4 will conduct. It takes time for the transistors to turn on, creating a propagation delay. This delay is typically very small, about 10 ns to 15 ns.



APPENDIX D. PROGRAMMING CABLE

Appendix D provides additional theoretical information for the Rabbit 2000® microprocessor when using the **DIAG** and **PROG** connectors on the programming cable. The **PROG** connector is used only when the programming cable is attached to the programming connector (header J1) while a new application is being developed. Otherwise, the **DIAG** connector on the programming cable allows the programming cable to be used as an RS-232 to CMOS level converter for serial communication, which is appropriate for monitoring or debugging a RabbitCore system while it is running.

The programming port, which is shown in Figure D-1, can serve as a convenient communications port for field setup or other occasional communication need (for example, as a diagnostic port). If the port is simply to perform a setup function, that is, write setup information to flash memory, then the controller can be reset through the programming port, and a cold boot is performed to start execution of a special program dedicated to this functionality.




Figure D-1. Programming Port Pin Assignments

When the **PROG** connector is used, the **/RESET** line can be asserted by manipulating the serial port **DTR** line and the **STATUS** line can be read as **DSR** on the serial port. The target can be restarted by pulsing reset and then, after a short delay, sending a special character string at 2400 bps. To simply restart the BIOS, the string 80h, 24h, 80h can be sent. When the BIOS is started, it can tell whether the programming cable is connected because the **SMODE1** and **SMODE0** pins are sensed as being high. This will cause the Rabbit 2000 to enter the bootstrap mode.

Alternatively, the **DIAG** connector can be used on the programming port. The **/RESET** line and the **SMODE1** and **SMODE0** pins are not connected when this connector is used, and are pulled low by resistors on the target board. The programming port is then enabled as a diagnostic port by polling the port periodically to see if communication needs to begin or to enable the port and wait for interrupts. The pull-up resistors on **RXA** and **CLKA** prevent spurious data reception that might take place if the pins floated.

If the clocked serial mode is used, the serial port can be driven by using two toggling lines that can be driven and one line that can be sensed. This allows a conversation with a device that does not have an asynchronous serial port but that has two output signal lines and one input signal line.

Once you establish that the programming port will never again be needed for programming, it is possible to use the programming port I/O for additional I/O lines. Table D-1 lists the pins available for this alternate configuration.

Table D-1. RabbitCore RCM2300 Programming Port Pinout Configurations

	Pin	Pin Name	Default Use	Alternate Use	Notes
Header J1	1	RXA	Serial Port A	PC6—Input	
	2	GND			
	3	CLKA		PB1—Bitwise or parallel programmable input	
	4	VCC			
	5	RESET	Reset (input only)		Connected to reset generator U1
	6	TXA	Serial Port A	PC7—Output	
	8	STATUS		Output	
	9	SMODE0		Input	Must be low when RCM2300 boots up
	10	SMODE1		Input	Must be low when RCM2300 boots up

Table D-2 lists the locations of these programming port I/O on headers J4 and J5.

Table D-2. Locations of Programming Port I/O on RCM2300 Headers J4 and J5

Programming Port Pin Name	Pin		Pin	
RXA	Header J4	7	Header J5	not connected
GND		1		26
CLKA		not connected		not connected
VCC		2		25
RESET		not connected		9*
TXA		8		not connected
STATUS		21		not connected
SMODE0		18		not connected
SMODE1		17		not connected

* This is not the same reset that is on the programming port. Refer to the schematic (090-0119) for more information.



APPENDIX E. SAMPLE CIRCUITS

This appendix details several basic sample circuits that can be used with the RCM2300.

- RS-232/RS-485 Serial Communication
- Keypad and LCD Connections
- External Memory
- D/A Converter

E.1 RS-232/RS-485 Serial Communication




Figure E-1. Sample RS-232 and RS-485 Circuits

Sample Program: `PUTS.C` in `SAMPLES/RCM2300`.

E.2 Keypad and LCD Connections




Figure E-2. Sample Keypad Connections

Sample Program: **KEYLCD.C** in **SAMPLES/RCM2300**.




Figure E-3. Sample LCD Connections

Sample Program: **KEYLCD.C** in **SAMPLES/RCM2300**. (When Parallel Port A is not being used for quick communication, its resting, quiescent value is used to set the LCD contrast level.)

E.3 External Memory

The sample circuit can be used to access 16 bytes on an external 64K memory device. Larger SRAMs can be written to using this scheme by using other available Rabbit 2000 ports (parallel ports A to E) as address lines to create up to four thousand 16-byte pages.




Figure E-4. Sample External Memory Connections

Sample Program: **EXTSRAM.C** in **SAMPLES/RCM2300**.

E.4 D/A Converter

The output will initially be 0 V to -10.05 V after the first inverting op-amp, and 0 V to +10.05 V after the second inverting op-amp. All lows produce 0 V out, FF produces 10 V out. The output can be scaled by changing the feedback resistors on the op-amps. For example, changing 5.11 k Ω to 2.5 k Ω will produce an output from 0 V to -5 V. Op-amps with a very low input offset voltage are recommended.




Figure E-5. Sample D/A Converter Connections



NOTICE TO USERS

Z-WORLD PRODUCTS ARE NOT AUTHORIZED FOR USE AS CRITICAL COMPONENTS IN LIFE-SUPPORT DEVICES OR SYSTEMS UNLESS A SPECIFIC WRITTEN AGREEMENT REGARDING SUCH INTENDED USE IS ENTERED INTO BETWEEN THE CUSTOMER AND Z-WORLD PRIOR TO USE. Life-support devices or systems are devices or systems intended for surgical implantation into the body or to sustain life, and whose failure to perform, when properly used in accordance with instructions for use provided in the labeling and user's manual, can be reasonably expected to result in significant injury.

No complex software or hardware system is perfect. Bugs are always present in a system of any size. In order to prevent danger to life or property, it is the responsibility of the system designer to incorporate redundant protective mechanisms appropriate to the risk involved.

All Z-World products are 100 percent functionally tested. Additional testing may include visual quality control inspections or mechanical defects analyzer inspections. Specifications are based on characterization of tested sample units rather than testing over temperature and voltage of each unit. Z-World products may qualify components to operate within a range of parameters that is different from the manufacturer's recommended range. This strategy is believed to be more economical and effective. Additional testing or burn-in of an individual unit is available by special arrangement.

INDEX

A

additional information
 Getting Started manual 3
 online documentation 3
 reference information 3

B

backup battery
 installing onboard battery . 42
 via header J5 41
 via optional header 43
 battery life 43
 battery-backup circuit
 external battery connec-
 tions 41, 43
 reset generator 44
 bus loading 26

C

clock doubler 12
 conformal coating 30

D

Development Kit 2
 DeviceMate 38, 39
 digital I/O
 I/O buffer sourcing and sink-
 ing limits 29
 memory interface 9
 SMODE0 9, 11
 SMODE1 9, 11
 digital inputs 9
 digital outputs 9
 dimensions
 Prototyping Board 34
 Dynamic C 15
 add-on modules 20
 libraries 17
 telephone-based technical
 support 20
 upgrades and patches 20

E

EMI
 spectrum spreader feature . 12
 exclusion zone 23
 external interrupts 18

F

features 1, 2
 flash memory addresses
 user blocks 13

I

I/O buffer sourcing and sinking
 limits 29

J

jumper configurations 31
 JP1 (flash memory size) 31
 JP2 (flash memory bank
 select) 13, 31
 jumper locations 31

M

manuals 3

P

physical mounting 25
 pin configurations 7, 9
 programming port 49
 pinout
 programming cable 48
 programming port 48
 Prototyping Board 37
 RCM2300
 J4 6
 J5 6
 power supplies 41
 chip select circuit 45
 Program Mode 16
 switching modes 16

programming cable47
 DIAG connector48
 pinout48
 PROG connector16
 programming port10
 pin configurations49
 pinout48
 used as diagnostic port48

Prototyping Board

adding RS-232 transceiver .38
 attach modules39
 dimensions34
 header JP1 location36
 optional connections to Rabbit
 2000 parallel ports36
 pinout37
 power supply35
 prototyping area37
 specifications34
 Vcc and GND traces37

R

Rabbit subsystems5
 Run Mode16
 switching modes16

S

sample circuits51
 D/A converter55
 external memory54
 keypad and LCD connec-
 tions53
 RS-232/RS-485 serial com-
 munication52
 serial communication10
 serial ports10
 programming port10
 software
 I/O drivers17
 libraries17
 PACKET.LIB17
 RS232.LIB17

readUserBlock	13
sample programs	19
PONG.C	19
serial communication driv-	
ers	17
writeUserBlock	13
specifications	21
bus loading	26
digital I/O buffer sourcing and	
sinking limits	29
dimensions	22
electrical, mechanical, and en-	
vironmental	24
exclusion zone	23
header footprint	25
headers	25
physical mounting	25
Prototyping Board	34
Rabbit 2000 DC characteris-	
tics	28
Rabbit 2000 timing diagram	
.....	27
relative pin 1 locations	25
spectrum spreader	12
subsystems	
digital inputs and outputs	5
switching modes	16



SCHEMATICS

090-0119 RCM2300 Schematic

www.rabbitsemiconductor.com/documentation/schemat/090-0119.pdf

090-0122 RCM2200/RCM2300 Prototyping Board Schematic

www.rabbitsemiconductor.com/documentation/schemat/090-0122.pdf

090-0128 Programming Cable Schematic

www.rabbitsemiconductor.com/documentation/schemat/090-0128.pdf

The schematics included with the printed manual were the latest revisions available at the time the manual was last revised. The online versions of the manual contain links to the latest revised schematic on the Web site. You may also use the URL information provided above to access the latest schematics directly.

